

NOTE:

and site dimensions. levels and sewer invert

and site dimensions, levels and sewer invert levels at connection points before work starts. This drawing must be read with and checked



The Contractor is to comply in all respects with the current Building Regulations whether or not specifically stated on these drawings. This drawing is not intended to show details of foundation or ground conditions. Each area of ground relied upon to support the structure depicted must be investigated by the Contractor and suitable methods of foundation be provided.

PRELIMINARY

Project Manager/ Checked	Drawn by BH	Scale AS NOTED@A1	Date OCT'2	Rev
Arch./Des.	Drawing			